

Regeneration and Remodeling of Materials



<http://www.foxnews.com/story/0,2933,307739,00.html>



<http://cache.eb.com/eb/image?id=98328&rendTypeId=4>

S.R. White, N.R. Sottos, J.S. Moore

FA9550-10-1-0255

**Depts. of Aerospace Engineering, Materials Science & Engineering, Chemistry
University of Illinois at Urbana-Champaign
& Beckman Institute for Advanced Science and Technology**

Report Documentation Page			Form Approved OMB No. 0704-0188		
Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.					
1. REPORT DATE AUG 2012		2. REPORT TYPE		3. DATES COVERED 00-00-2012 to 00-00-2012	
4. TITLE AND SUBTITLE Regeneration and Remodeling of Materials			5a. CONTRACT NUMBER		
			5b. GRANT NUMBER		
			5c. PROGRAM ELEMENT NUMBER		
6. AUTHOR(S)			5d. PROJECT NUMBER		
			5e. TASK NUMBER		
			5f. WORK UNIT NUMBER		
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) University of Illinois at Urbana-Champaign, Depts. of Aerospace Engineering, Materials Science & Engineering, Chemistry, Urbana, IL, 61801			8. PERFORMING ORGANIZATION REPORT NUMBER		
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)			10. SPONSOR/MONITOR'S ACRONYM(S)		
			11. SPONSOR/MONITOR'S REPORT NUMBER(S)		
12. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release; distribution unlimited					
13. SUPPLEMENTARY NOTES Presented at the 2nd Multifunctional Materials for Defense Workshop in conjunction with the 2012 Annual Grantees'/Contractors' Meeting for AFOSR Program on Mechanics of Multifunctional Materials & Microsystems Held 30 July - 3 August 2012 in Arlington, VA. Sponsored by AFRL, AFOSR, ARO, NRL, ONR, and ARL. U.S. Government or Federal Rights License					
14. ABSTRACT					
15. SUBJECT TERMS					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT Same as Report (SAR)	18. NUMBER OF PAGES 20	19a. NAME OF RESPONSIBLE PERSON
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified			

Outline

- Program overview
- Regenerative coatings
 - acrylic system
 - surface microvalves
- Dynamic polymer
 - bi-phase system
 - regeneration experiments
- Multiscale scaffolds
- Summary

Autonomous Materials Systems Group

Regeneration & Remodeling Team



Ryan Gergely (AE)



Windy Turchyn (Chem)



Brett Krull (MatSE)

Concepts and Motivation


Regeneration and Remodeling in biology:

Tree skink lizard



Linckia starfish

Human Bone



Key Features:

- Large scale damage volume
- Repeatability and Reversibility
- Orders of magnitude change in properties
- Autonomy
- Stress activation

Benefits:



- Selective restructuring
- Response to environmental stimuli
- Reduction in parasitic weight
- Anti-aging
- Self-repair

Overview


Regeneration in biology:



Our approach: *Dynamic polymers*



+ *inert scaffolds*





GOAL: To develop bio-inspired composite material systems that regenerate and remodel in response to environmental stimuli.

Outline

- Program overview
- Regenerative coatings
 - acrylic system
 - surface microvalves
- Dynamic polymer
 - bi-phase system
 - regeneration experiments
- Multiscale scaffolds
- Summary

Coating Regeneration

Concept:



Coating Damage
Triggers Release



Delivery of
Uncured Coating

Vasculature
Substrate



- Current healing technology targets small scale damage (cracks)
- Extensive damage is difficult to heal
- Channel blockage is a challenge

Surface Microvalves

Prior Results






Valved Pores Prevent Curing into Delivery Network




Valve Network Design

valve network




Valve Flow Characteristics






Outline

- Program overview
- Regenerative coatings
 - acrylic system
 - surface microvalves
- Dynamic polymer
 - bi-phase system
 - regeneration experiments
- Multiscale scaffolds
- Summary

Bi-Phase Chemical Resin



-  Acylhydrazone end-functionalized PEG oligomer
-  Tri-aldehyde crosslinker
-  Methacrylate liquid monomer (HEMA)

Deng et al. *Macromolecules*, 2010, 43, 1191-1194

Sol

- Concept:** Low viscosity solution for easy delivery via microvascular networks
- Design:** Consists of gelator components in liquid monomer “solvent”

Gel

- Concept:** Rapid viscosity increase to a semi-solid as first transition
- Design:** Acid catalyst initiates gel formation at time, t_1


Polymer Solid

- Concept:** A second stage transition for recovery of mechanical strength of damaged region
- Design:** Monomer (HEMA) polymerizes at time, t_2 , by initiator/promoter

Individually Tunable Chemistries

t_1 Gel Time


Controlled by acid catalyst & amount of gelators



t_2 Polymerization Time

Room Temp. Polymerization Components

- Initiator – MEKP
- Promoter – CoNp




(Polymerization: 0.3 wt% CoNp, 15 v/v% acetic acid catalyst)

Scaffold for Large Damage Volume

$$p_c = \frac{2\gamma \cos \theta}{r}$$

Infiltrate Scaffold

- Small pores fill with resin due to surface tension
- Sufficient healing agent delivery possible smaller volumes



Gel Scaffold

- 2-component bi-phase gel/polymer system
- Gradual material deposition and solidification
- Gel network scaffold fills large volumes
- Subsequent polymerization and recovery of virgin properties

Part A


Monomer
Acid Catalyst
Gel Part 1

Part B


Monomer
Gel Part 1
Gel Part 2

Large Damage Volume Regeneration


Damage Regeneration Setup




Damage Fill Pumping Regime




Microchannels in Specimen




3.5 mm gap (PDMS healing system)




5.0 mm gap with bi-phase resin




4.0 mm gap (PDMS healing system)



Damage Filling Results




Multi-Scale Scaffold




- **Concept:** Larger damage volumes can be regenerated using multiple scale scaffolds
- **Coarse Scaffold:** Fiber bridging/pullout
- **Molecular Scaffold:** Gel of bi-phase material

Fiber Bridging:

Carbon Fiber Reinforced Epoxy




Short Glass Fiber Reinforced Nylon



Segregation of Damage Volume via Fiber Pullout

Specimen Geometry



Single Edge Notched Tension (SENT) 5x Speed

200 μ m Nylon
Monofilament

Notch

330 μ m
Channels



5 mm

2 mm


5 mm

Fill Testing of Bridged Region


Vertical Orientation: Vajrota Premixed



Failure




Success



Summary


- **Embedded Valve Systems**

- Mitigates blockage of network for multiple healing cycles
- Autonomic delivery via pressure actuation



- **Bi-phase, 2-part Resin Chemistry**

- Tunable kinetics for each constituent
- Facile delivery of low viscosity, 2-part gel/resin system
- Exceeds surface tension limitations to fill large volumes



- **Regeneration of composite materials**

- Fiber bridging as vehicle for regenerative healing
- Combined with bi-phase system, multi-scale scaffolds

